


Description of temperature sensor components



Description of positions according to the installation manual

pos.2 - screw fitting

pos.3 - temperature sensor

pos.4 - swivel nut

pos.5 - loop